Caring for Your Jacuzzi with Bromine

Upon fill up:

- 1. Add 2oz of **Sodium Bromide** directly to water
- 2. Insert Jacuzzi Proclear Cartridge into filter or onto filter basket
- 3. Pour one half (250 gallon spas or less) or one full bottle (250+ gallon spas) of **Metal Gon** directly into water
- 4. Add 2 oz. of **Renew** directly into water
- 5. Add 2 oz. of **Defender** directly into water
- 6. Wait at least 12 hours and check Ph with **Test Strip**
- 7. Adjust Ph as necessary with **Spa Up** or **Spa Down**
- 8. Place 1-3 1" Bromine Tablets in skimmer next to filter(s)

Thursday Maintenance:

- 1. Add 2 oz. of **Defender** directly to water
- 2. Check and add **Bromine Tablets** as necessary

Sunday Maintenance:

- 1. Check Ph with **Test Strip** and adjust as necessary
- 2. Add 2 oz. (per 250 gallons) of Renew directly to water
- 3. Check and add **Bromine Tablets** as necessary

Weekly or as needed:

- 1. Add 2 oz. of **Bright & Clear** if water is cloudy
- 2. Add 2 oz. of **Enzyme** if spa develops a scum line around water
- 3. Add 2 oz. of **Foam Down** if water is excessively foamy
- 4. Spray out filters with high pressure garden hose

Monthly:

- 1. Apply Cover Care & Conditioner to cover to protect from UV rays
- 2. Remove filters from the spa. Spray down with **Instant Cartridge Clean**, let soak 20 minutes in the shade (so they don't dry), rinse filters thoroughly and reinstall into spa.

Every 3-4 Months:

- 1. Drain spa and wipe down shell with a cotton towel. Once dry, apply a thin layer of **Fast Gloss** to the shell, allow 15 minutes to dry, and wipe off with a clean cotton towel. Spray out shell and use a wet/dry vacuum to remove any remaining Fast Gloss left on the shell.
- 2. Dilute one bottle of **Filter Clean** in four gallons of water and allow filters to soak for at least three hours. Rinse filters thoroughly and reinstall into spa.
- 3. Refill spa and refer to the Upon fill up portion above